

Linksys Router Port Forwarding Setup for iDVR-E

1. Log into your Linksys Router by typing the following gateway into a web browser
`http://192.168.1.1` [By default Username and Password are both **admin**]
2. Once you are logged into your Linksys router click "**Applications & Gaming**" > "**Single Port Forwarding**". [If "Single Port Forwarding" is not an option than select "Port Range Forwarding"]

The screenshot displays the Linksys WRT600N router's web interface. The top navigation bar includes 'Applications & Gaming', 'Setup', 'Wireless', 'Security', 'Storage', 'Access Restrictions', 'Applications & Gaming' (highlighted), 'Administration', and 'Status'. Below this, the 'Single Port Forwarding' sub-menu is also highlighted. The main content area features a table for configuring port forwarding rules.

| External Port | Internal Port | Protocol | To IP address | Enabled |
|----------------------|----------------------|----------|-------------------|--------------------------|
| --- | --- | --- | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| --- | --- | --- | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| --- | --- | --- | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| --- | --- | --- | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| --- | --- | --- | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |
| <input type="text"/> | <input type="text"/> | TCP | 192 . 168 . 1 . 0 | <input type="checkbox"/> |

At the bottom of the page, there are 'Save Settings' and 'Cancel Changes' buttons, and the Cisco Systems logo is visible in the bottom right corner.

3. Now in one of the empty Application Fields fill in the below info.

| Application Name | External Port | Internal Port | Protocol | To IP Address | Enabled |
|------------------|---------------|---------------|----------|---------------|--------------------------|
| | --- | --- | --- | 192.168.1.0 | <input type="checkbox"/> |

Application Name: iDVR-E

External Port: 7000

Internal Port: 7000

Protocol: TCP

To IP address: IP Address of the iDVR-E

Check the Enable Box

4. Click the "**Save Settings**" button near the bottom of the screen.