

Comcast TC8305C Port Forwarding Setup Instructions for Zavio NVC

NVR



In the picture above the address bar has `http://www.google.com/` in it. Just replace all of that with the internal IP address of your Technicolor TC8305C router. By default the IP address should be set to 10.0.0.1.



You should see a box prompting you for your username and password. Enter your username and password now.

The Default Username is: **admin**

The Default Password is: **password**

Now that you are logged in to your Technicolor TC8305C router you should see the following:



Click the **Advanced** link near the left of the page.

You should now see a new menu. In this new menu, click **Port Forwarding**.



Click the **Add Service** button near the center of the page.

The screenshot shows the Xfinity Advanced Port Forwarding 'Add Service' form. The page title is 'Advanced > Port Forwarding > Add Service'. On the left is a navigation menu with 'Advanced' selected, containing sub-items like 'Port Forwarding', 'Port Triggering', 'DMZ', 'Dynamic DNS', 'Device Discovery', and 'Troubleshooting'. The main form area has a header 'Add Service' and a text area for email notifications. Below are fields for 'Services Name' (set to 'Other'), 'Other Service', 'Service Type' (set to 'UDP'), 'Server IP Address' (with three input boxes), 'Start Port', and 'End Port'. 'SAVE' and 'CANCEL' buttons are at the bottom. A watermark 'PortForward.com' is visible across the form. The footer contains 'Xfinity.com', 'customerControl', and 'User Guide'.

Now fill in as follows..

Other Service: This can be anything this is only for reference.

Service Type : TCP

Server IP Address: IP address of NVR

Start Port: 80

End Port: 80

Now click **Save**.

Repeat this step for ports 5150, 5160, and 5170 as well.