

DLINK Router Port Forwarding Setup for Nuuo Mini NVR

1. Log into your DLink Router by typing the following gateway into a web browser
<http://192.168.0.1> [By default Username: **admin** and Password: **password**]
2. Click "**Advanced**" > "**Port Forwarding**"

The screenshot shows the D-Link WBR-1310 router's web interface. The top navigation bar includes 'WBR-1310', 'SETUP', 'ADVANCED' (highlighted with a red box), 'TOOLS', and 'STATUS'. The left sidebar lists various settings, with 'PORT FORWARDING' highlighted in red. The main content area is titled 'PORT FORWARDING RULES' and contains a descriptive paragraph, two buttons ('Save Settings' and 'Don't Save Settings'), and a table of 20 port forwarding rules.

PORT FORWARDING RULES :
The Port Forwarding option is used to open a single port or a range of ports through your firewall and redirect data through those ports to a single PC on your network.

20- PORT FORWARDING RULES

	Name	IP Address	Port	Traffic Type	Schedule
<input type="checkbox"/>	<input type="text"/> Application Name	<input type="text"/> Computer Name	Start 0 End 0	Any	Always
<input type="checkbox"/>	<input type="text"/> Application Name	<input type="text"/> Computer Name	Start 0 End 0	Any	Always
<input type="checkbox"/>	<input type="text"/> Application Name	<input type="text"/> Computer Name	Start 0 End 0	Any	Always

3. Now in one of the empty Application Fields fill in the below info.

Name: Nuuo Mini 1

IP Address: IP Address of the Nuuo Mini

Port Start: 80

Port End: 80

Traffic Type: Any

Schedule: Always

Make sure the Enable Box is checked to the left of the rule.

Repeat for ports 5150, 5160 and 5170.

4. Click the "**Save Setting**" button.