


Comcast SMC Router Port Forwarding Setup for NUUO NVR Solo

1. Login into your Comcast SMC router by typing the following gateway into a web browser
<http://10.1.10.1> [By Default Username: **cusadmin** password: **highspeed**]
2. Click "**Firewall**" > "**Port Forwarding**" > "**Add New**"



3. Now fill in the below:

Application Name: NUUO NVR Solo 1

Port Range: 80

Protocol: Both

IP Address: IP Address of the NUUO NVR Solo

Do the above for port 80, 5150 and 5160

4. Press the "**Apply**" button to save the settings.