

- Now in one of the empty Application Fields fill in the below info.

Application Name	External Port	Internal Port	Protocol	To IP Address	Enabled
	---	---	---	192.168.1.0	<input type="checkbox"/>

Application Name: Zavio NVC NVR

External Port: 80

Internal Port: 80

Protocol: TCP

To IP address: IP Address of the NVR

Check the Enable Box

Do the above for ports 80, 5150, 5160, and 5170.

- Click the "**Save Settings**" button near the bottom of the screen.