
<u>Airport Extreme Router Port Forwarding Instructions for</u> <u>Zavio IP Cameras</u>


- 1. Go to your **Finder** menu and type "**Airport**" into the search box and find your **Airport Utility** program.
- 2. If you are prompted for manual configuration, select Manual.
- 3. Find the **Advanced Tab** at the top and select it.
- 4. Now choose the **Port Mapping** option. (On some it may be known as the "IPV6Firewall")



5. To forward the port of your device, first select the Zavio IP Camera from the list as seen above. Then click the "+" sign at the bottom and a menu similar to the one below will appear.



6. Once it appears, leave the "Choose a service" dropdown menu untouched. Now enter the Private IP Address for the Zavio IP Camera as it appears in the IP scanner. Assign a port number to the camera in the Public TCP Ports section, this could be any available number you like. In this case let's do port 80. (Please note that each camera must have its own unique port number and must be the same number as the one in the camera's network settings) Then click Continue.



7. Now for the **Description** and **Service Name** tab as shown above let's put the name of your Zavio IP Camera. This is for your reference, I recommend something like "Zavio 1". Once complete, go ahead and click **Done** to save the **Port Mapping** settings.